Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

Bunker Hill Security®

Digital Drawer Safe

Batteries sold separately.
To ensure security of your safe, Bunker Hill Security does NOT provide replacement keys.

REV 13h

Visit our website at: http://www.harborfreight.com
Email our technical support at: tech@harborfreight.com

ITEM 97644

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-800-444-3353 as soon as possible.

Copyright© 2008 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.
Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠WARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Specifications

Overall Dimensions	14" L x 12" W x 5" H
Batteries	4 - AA (sold separately)

IMPORTANT SAFETY INFORMATION

Installation Precautions

1. Verify that installation surface has no hidden utility lines before drilling or driving screws.
2. Wear ANSI-approved safety goggles during installation.
3. Mount securely before use.
4. Install only according to these instructions. Improper installation can create hazards.
5. Keep installation area clean and well lit.
6. Keep bystanders out of the area during installation.
7. Do not install when tired or when under the influence of alcohol, drugs, or medication.
8. Place the Safe on correct surface. Only use this Safe on a stable, level, clean and dry surface that is capable of sustaining the load.

Use Precautions

1. **Keep closed and locked whenever unattended. Check inside before closing. Do not allow children to play with or near safe. Keep keys and codes away from children.**
2. Keep clear of door when closing.
3. Position batteries in proper polarity and do not install batteries of different types, charge levels, or capacities together.
4. Use as intended only.
5. Inspect before every use; do not use if parts are loose or damaged.
6. Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.
7. Do not store Keys inside of the Safe. **Place the emergency keys in a location outside of the safe making sure they are in a secure location that you can find.**
8. The lid has a ratchet mechanism which automatically swings downward, engaging the ratchet teeth and locking the lid in the open position. Be sure the lock is engaged so the lid does not slam down suddenly.
9. Warning: The brass components of this product contain lead, a chemical known to the State of California to cause birth defects (or other reproductive harm). (California Health & Safety code § 25249.5, et seq.)
10. The drawer the Safe is placed into must support the weight of the Safe and its load.
11. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.
12. The Safe is neither water nor fire proof.

NOTE: Harbor Freight Tools is not responsible for the loss of any property stored within this safe due to theft, fire, or any other circumstance.

Installation

Mounting

1. The mounting location must be able to support the weight of both the safe and its contents.
2. Using the holes in the bottom of the Safe as a template, lay the Safe in the desired location and drill pilot holes at two opposite corner holes.
3. Once the two pilot holes have been drilled, secure the Safe with two of the four supplied 1-1/2” wood screws.
   a. Screw through the holes in the bottom of the Safe and into the drawer bottom.
   b. If the screws included with the Safe are too long, replace them with the appropriate length wood screws (not supplied) for the intended mounting surface.
4. Once secured in position, drill the other two pilot holes and screw in the last two wood screws.
5. Place the supplied felt pad in the Safe so as to cover the Safe bottom and mounting screws.

Batteries

1. Remove the battery cover on the inside of the lid to expose the battery compartment.
2. Insert four AA batteries, taking note of the proper polarity. Then replace the battery cover.

Operation

Open Safe Using Emergency Keys

Note: The Emergency Override Keys are provided for opening the Safe upon purchase, and as a failsafe for when the batteries run down or you forget the code.

1. Pry off the key-lock cover, insert the key into the lock, and turn. Lift the handle and open the lid.
2. The ratchet lid support will automatically hold the lid at the “open” position. Be sure the lid is open at least 3-4" or 30°, allowing the ratchet lock-tab to engage the ratchet teeth.
3. To close the lid, lift the lid up and back as far as it will go, disengaging the ratchet-lock, and lower to the closed position. The lid will not close unless it has been fully opened first.

Note: If an incorrect code is entered three times, the system will not accept code input for 20 seconds.

Set the Combination Code

1. Press the “keypad reset button” found on the hinge side of the Battery Compartment.
2. Enter a new code, using 3-8 numbers, followed by the letter “B”. Upon entering the new code, the Safe will unlock and the green LED will light.

Note: The keypad will also accept nine digits without a letter as a new code.

3. Make sure the Override Keys are not in the Safe. Lock the Safe and test the new combination. If something goes wrong, use the Override Keys to open the Safe.

LED LIGHTS

Green	Unlocked
Yellow	Enter new code
Red	Low battery level.

Maintenance

1. **BEFORE EACH USE**, inspect the general condition of the Safe. Check for loose screws, misalignment or binding of moving parts, cracked or broken parts, damaged electrical wiring, and any other condition that may affect its safe operation.
2. **PERIODICALLY** clean external surfaces of the Safe with a clean cloth.
3. To replace the four AA batteries that power the keypad, remove the battery cover on the inside of the lid exposing the battery compartment. Remove the batteries, taking note of the proper polarity, and install the new batteries the same way.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Record Product's Serial Number Here:_____

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

Bunker Hill Security®

3491 Mission Oaks Blvd. • PO Box 6009 • Camarillo, CA 93011 • (800) 444-3353